

Additional Instruction

UNIVERSAL

'82, January

B. DRAWING OF CIRCUIT BOARD MOUNTING POSITIONS




Fig. 5 Circuit Board Mounting Positions




Fig. 6 Side View of Circuit Board Mounting Positions

C. FUSES

Fuses in the power source unit





Fig. 7 Fuses in the Power Source Unit

VIII. CIRCUIT BOARD

A. CIRCUIT BOARD IC LOCATION AND PARTS LIST

a) Main circuit board IC location and parts list



This drawing provides standard information. Universal reserves the right to change without notice.

Fig. 22 Main Circuit Board

[1] Integrated Circuit

| Item No. | Q'ty | Description |
|------------------------|------|--|
| 74LS 00 | 3 | TTL |
| 74LS 02 | 3 | " |
| 74LS 04 | 5 | " |
| 74 04 | 1 | " |
| 74 S 04 | 1 | " |
| 74LS 08 | 11 | " |
| 74LS 10 | 2 | " |
| 74LS 20 | 1 | " |
| 74LS 27 | 1 | " |
| 74LS 32 | 3 | " |
| 74LS 42 | 1 | " |
| 74LS 74 | 9 | " |
| 74LS 86 | 7 | " |
| 74LS107 | 2 | " |
| 74LS138 | 3 | " |
| 74LS151 | 2 | " |
| 74LS153 | 4 | " |
| 74LS155 | 1 | " |
| 74LS157 | 13 | " |
| 74LS161 | 9 | " |
| 74LS166 | 2 | " |
| 74LS174 | 6 | " |
| 74LS175 | 2 | " |
| 74LS244 | 2 | " |
| 74LS245 | 1 | " |
| 74LS253 | 5 | " |
| 74LS259 | 1 | " |
| 74LS273 | 8 | " |
| 74LS283 | 4 | " |
| 74 S288 (TBP18S030) | 3 | 256 bits Bipolar RAM |
| 74LS393 | 2 | TTL |
| 74LS395 | 5 | " |
| NE555 | 1 | Timer |
| NE556 | 1 | " |
| Z80A | 1 | Nch MOS CPU (4MHz) |
| 2732 | 4 | Nch MOS 32K bits EP ROM (Access 450nsec) |
| 2732-35 | 6 | Nch MOS 32K bits EP ROM (Access 350nsec) |
| 2114 | 8 | Nch MOS 4K bits Static RAM (Access 450nsec) |
| 2114-2 | 9 | Nch MOS 4K bits Static RAM (Access 250nsec) |
| U8106 | 2 | Special function |
| LM324 | 1 | Quad Operational Amplifiers |
| MB3730 | 1 | Power Amplifiers |
| MA7805 | 1 | Regulator |

[2] Other Semiconductor Devices

| Item No. | Q'ty | Description |
|----------|------|-------------|
| TLR103 | 1 | LED |
| 10D1 | 6 | Diode |

[3] Capacitors

| Rating | Q'ty | Description |
|-----------|------|--------------------|
| 100P1/12V | 2 | Ceramic Capacitor |
| 0.001μ/ " | 1 | " |
| 0.01μ/ " | 2 | " |
| 0.1μ / " | 54 | " |
| 0.1μ/25V | 3 | " |
| 1μ/25V | 1 | Chemical Capacitor |
| 47μ/25 | 2 | " |
| 4.7μ/25V | 2 | " |
| 10μ/ " | 2 | " |
| 22μ/ " | 1 | " |
| 220μ/ " | 4 | " |
| 470μ/ " | 2 | " |

[4] Registers

| Rating | Q'ty | Description |
|---------------------|------|------------------------------|
| 20Ω¼W | 1 | Carbon Solid |
| 2KΩ¼W | 2 | " |
| 100Ω¼W | 2 | " |
| 4.7Ω " | 2 | " |
| 47Ω " | 1 | " |
| 220Ω " | 18 | " |
| 330Ω " | 2 | " |
| 470Ω " | 6 | " |
| 510Ω " | 4 | " |
| 1KΩ " | 1 | " |
| 4.7KΩ " | 1 | " |
| 5.1KΩ " | 1 | " |
| 10KΩ " | 2 | " |
| 47KΩ " | 1 | " |
| 51KΩ " | 1 | " |
| 100KΩ " | 3 | " |
| MS1028AM | 8 | 1KΩ Register Array |
| MS1024AM | 1 | " |
| MS1038AM | 2 | 10KΩ Register Array |
| RV16YP or RGP102 | 1 | 1KΩ (B) Variable Register |

[5] Misc

| Name | Q'ty | Description |
|---------|------|-------------------------|
| Dip SW | 2 | 8 Elements Switch Array |
| X tal | 2 | 9.828MHz 4.000MHz |
| E61-00A | 1 | Micro SW |

WIRING DIAGRAM (CONNECTOR)






TABLE TYPE



LADY BUG

8110

SWITCHING REGULATOR – LOCATION, PARTS LIST AND SCHEMATIC DIAGRAM



| Rating | Q'ty | Description |
|---------------|------|------------------------------|
| 0.5Ω 5W | 1 | Wire wound resistor |
| 100Ω 2W | 2 | " |
| 150Ω 4W | 2 | " |
| 50Ω 2W | 2 | " |
| 180kΩ ½W | 2 | Carbon film resistor |
| 5Ω ½W | 1 | " |
| 100kΩ ¼W | 2 | " |
| 2.1kΩ " | 1 | " |
| 20kΩ " | 2 | " |
| 10kΩ " | 1 | " |
| 2.2Ω " | 1 | " |
| 330Ω " | 1 | " |
| 15Ω " | 2 | " |
| 24Ω " | 2 | " |
| 5kΩ | 3 | Metal film resistor |
| 4.3kΩ | 1 | " |
| 1.0φ, 8cm | 1 | Resistor for current sensing |
| 25kΩ 201/375S | 1 | Variable resistor |
| | | |
| 0.068μF/250V | 1 | PPN capacitor |
| 160μF/200V | 2 | Electrolytic capacitor |
| 1000μF/35V | 2 | " |
| 220μF/25V | 1 | " |
| 2200μF/16V | 1 | " |
| 4.7μF/25V | 1 | " |


| Rating | Q'ty | Description |
|---------------------|------|------------------------|
| 3300 μ F/16V | 1 | Electrolytic capacitor |
| 330PF/1000V | 2 | Ceramic capacitor |
| 1000PF/1000V | 3 | " |
| 0.0047 μ F/100V | 1 | Mylar capacitor |
| 0.033 μ F/100V | 1 | MEF capacitor |
| 1000PF/100V | 1 | PEE capacitor |

| Item No. | Q'ty | Description |
|----------|------|----------------------------|
| MJE13005 | 2 | Switching power transistor |
| MB3759 | 1 | PWM control circuit |
| RG1J | 2 | Fast recovery diode |
| GP20G | 2 | Rectifier |
| 10D4 | 2 | " |
| S5KC20 | 1 | TO-220 package |
| S10SC4M | 1 | " |
| 1N4148 | 2 | Switching diode |


| Name | Q'ty | Description |
|--------------------------|------|----------------------------|
| Power transformer | 1 | For inverter |
| " | 1 | For MB3759 control circuit |
| Pulse transformer | 2 | For base drive |
| 1.6mH input line filter | 1 | |
| +12V output filter chock | 1 | |
| +5V " | 1 | |
| Fuse | 1 | 2A |

LADY BUG

8110




SCHEMATIC DIAGRAM (20" color)



Unless designed, resistance is of 1/4W;
Unless designed, condenser withstand voltage is 50V;

Note: 1. Use CN2B when reversing the polarity of D1.
2. This schematic drawing represents the basic layout. It may differ from the actual layout.
3. C44 TAC type 0.47/200 FPD type 0 (I-R) Incombustible resistance
4. C76 backed



CM-E20N(B)

LADY BUG

8110

CAUTION (to prevent X-ray exposure from the CRT)

Two variable resistors, the +B ADJ VR (VR11 8-1K ohm) and the X-ray protector VR (VR8 B-10K ohms) are found within the monitor.

They are rigidly adhered for both safety and to prevent X-ray exposure from the CRT.

(IMPORTANT: Please do not remove or change them!)

When a component has to be replaced due to damage to the VR(s) please follow the following procedure when exchanging it.

(IMPORTANT: The monitor must be synchronized with the signal when adjusting.)

(1) To set for +B ADJ VR (VR11)

+B line voltage is to be set at 107V DC \pm 1V when adjusting VR11.

(2) To set for X-ray protector VR8

(2)-1. Place VR in a counter clockwise position to stop it before turning the monitor power switch to "ON" and decrease AC power supply voltage by approximately 10%.

(2)-2. To be shorted for resistor of 220 ohms 20W R201 which is installed on heat sink plate.

(2)-3. Power supply should be placed in the "ON" position to keep the surface of the CRT slightly fluorescent — i.e. bright.

(2)-4. +B line voltage is to be set at 123V DC \pm 1V while increasing AC power supply voltage.

(2)-5. When the VR8 to be fixed is in the horizontal oscillation position it may be stopped by slowly rotating it clock wise.

(2)-6. Once the power supply switch is turned "OFF" and AC power has decreased approximately 10% it can be turned "ON" again. Horizontal oscillation may then be confirmed by stopping +B line voltage at 123V DC \pm 1V while slowly increasing AC voltage.

(3) The VR must again be rigidly adhered thus making any further adjustments impossible.

If you have any question about the above, please feel free to contact us directly or your nearest Universal distributor at any time.

